

MIGEL



اتو بخار

GSI 230

English

فارسی

مشتري گرامی ضمن تشکر از حسن سلیقه و اعتماد شما به برند میگل امیدواریم از کار با این دستگاه لذت ببرید.

مشخصات فنی

مدل	توان	ولتاژ	فرکانس
GSI230	۱۹۵۰-۲۳۰۰ وات	۲۲۰-۲۴۰ ولت	۵۰/۶۰ هرتز

نکات ایمنی

۱. قبل از استفاده از اتو این دفترچه راهنما را با دقت مطالعه کنید و آن را نزد خود نگه دارید.
۲. قبل از اتصال سیم برق اتو به پریز برق، از مطابقت ولتاژ شهری با ولتاژ درج شده بر روی لیبل پشت اتو مطمئن شوید.
۳. قبل از پر کردن مخزن آب و تخلیه کردن آن سیم برق را از پریز برق جدا کنید. زمان جدا کردن سیم برق از دوشاخه، سیم و دوشاخه را همراه با هم نگه داشته و از پریز جدا نمایید.
۴. بعد از اتمام کار مخزن آب را تخلیه کنید. قبل از تخلیه مخزن آب مطمئن شوید که سیم برق از پریز جدا شده است.
۵. سیم برق را از اجسام گرم و کفی اتو دور نگه دارید.
۶. همیشه دوشاخه دستگاه را به پریزی که دارای اتصال زمین است وصل کنید. در صورتی که نیاز داشته باشید از کابل دیگر جهت گسترش طول سیم استفاده نمایید، کابل باید دارای سیم اتصال زمین باشد و حداقل سطح مقطع سیم های داخل کابل باید یک میلی متر مربع باشد.
۷. برای جلوگیری از خطر برق گرفتگی، اتو را داخل آب فرو نبرید.
۸. به منظور جلوگیری از خطر، همیشه از اتو بر روی سطح صاف و ثابت استفاده کنید.
۹. بعد از اتمام اتوکشی، اتو را در حالت عمودی قرار دهید و صبر کنید تا سرد شود، هنگامی که مابین اتوکشی می‌خواهید اتو را رها کنید عمل مشابه را انجام دهید. حتماً اتو را بر روی سطح صاف و ثابت قرار دهید.
۱۰. اتو را دور از دسترس کودکان و افراد ناتوان فیزیکی قرار دهید و استفاده کنید. هنگامی که دستگاه داغ است آن را بدون مراقبت نزدیک کودکان و افراد ناتوان فیزیکی رها نکنید.
۱۱. هرگز سعی نکنید، لباسی که به تن دارید را اتو کنید.
۱۲. اگر سیم برق آسیب دید، برای جلوگیری از مخاطرات برای تعویض کردن آن را

به خدمات پس از فروش تحویل دهید.

۱۳. بعد از اینکه اتو روی زمین افتاد و آسیب دید و یا دچار نشستی آب شد از آن استفاده نکنید و فوراً با خدمات پس از فروش تماس حاصل نمایید.

۱۴. اگر اتو به هر دلیلی دچار شکستگی شد، از آن استفاده نکنید و به خدمات پس از فروش مراجعه نمایید.

۱۷. این اتو مطابق با استانداردهای ایمنی بین المللی است.

۱۸. مخزن آب اتو را بیش از حد پر نکنید، در غیر اینصورت آب سرریز می شود. برای جلوگیری از سرریز شدن آب، اتو را در حالت عمودی نگه دارید و آب را تا علامت MAX داخل مخزن بریزید.

۱۹. کفی اتو قبل از تولید بخار باید به دمای مشخص برسد. زمانی که تنظیم گر بر روی بخار تنظیم می شود، عملکرد ضدچکه از چکیدن آب تا زمانی که کفی به اندازه کافی گرم شود جلوگیری میکند.

۲۰. قبل از اولین استفاده، داخل مخزن آب بریزید، اجازه دهید آب تبخیر شود، این فرآیند را دوبار تکرار کنید. هنگام فرآیند تبخیر، دکمه بخار را در به صورت مکرر فشار دهید. در نتیجه عملکرد بخاردهی بهبود می یابد و ذرات گردو غبار از مخزن بخار خارج میشوند.

۲۱. اگر آب لوله کشی محل زندگی شما آهک زیادی دارد، به شما توصیه می شود که قبل از پر کردن مخزن آب، آن را با آب تصفیه شده مخلوط کنید.

۲۲. هنگام نخستین بار استفاده از دستگاه، متصاعد شدن اندکی بوی نامطبوع از اتو امری کاملاً طبیعی است.


۲۳. اگر در هنگام اتوکشی آب مخزن تمام شد، سیم برق را از پریز برق جدا کنید و بدون اینکه صبر کنید تا اتو سرد شود آب را داخل مخزن اضافه کنید.

۲۴. اگر عملکرد اسپری کننده عمل نکرد، برای از بین بردن هرگونه انسداد، خروجی اسپری کننده را با انگشت بندید و دکمه اسپری را چندبار فشار دهید.

۲۵. اول باید لباسهایی که به دمای کم برای اتوکشی نیاز دارند اتوشوند، آنهایی که به دمای بالا نیاز دارند باید بعد اتوکشی شوند. اگر شما تنظیم گر دما را از دمای بالا به دمای پایین کاهش دهید، باید ۳-۴ دقیقه تا سرد شدن اتو و کاهش دما صبر کنید.

۲۶. عملکرد ضدچکه این اتو باعث میشود زمانی که دمای کفی اتو تغییر کرد یک صدای "کلیک" پخش کند، که این عادی است.

۲۷. قبل از اولین استفاده از این اتو، پوشش محافظ را از روی کفی بردارید.



- | | |
|-------------------|------------------------|
| ۱. سیم برق | ۶. تنظیم گر بخار |
| ۲. تنظیم گر دما | ۷. دکمه اسپری کننده آب |
| ۳. کفی | ۸. دکمه بخار لحظه ای |
| ۴. اسپری کننده آب | ۹. چراغ تنظیم گر دما |
| ۵. در پوش مخزن آب | |


نحوه استفاده


همیشه قبل از ریختن آب در مخزن ، سیم برق را از پریز برق جدا کنید.

آب ریختن داخل مخزن

- دوشاخه را از پریز برق جدا کنید. تنظیم گر بخار را در جهت خلاف عقربه های ساعت در حالت "0" قرار دهید.

- درپوش مخزن را باز کنید، دستگاه را در حالت افقی نگه دارید، به آرامی درب مخزن را باز کرده و آب را داخل آن بریزید. مطمئن شوید وقتی که دستگاه را به حالت افقی نگه می دارید ، میزان آب از علامت





مشخص شده MAX روی مخزن تجاوز نمی‌کند.


- درپوش مخزن را ببندید.
- حتی اگر از بخار برای اتوکشی استفاده نمی‌کنید، آب

داخل مخزن بریزید، بنابراین هر زمان که تمایل داشتید می‌توانید از عملکرد اسپری استفاده کنید.

- هرگونه مواد معطر، سرکه، آهار، مواد رسوب زدا، مکمل های اتوکشی و مواد شیمیایی دیگر را به مخزن آب اضافه نکنید.

- اگر آب شیر محل شما بسیار آهکی باشد، به شما پیشنهاد می‌شود قبل از ریختن آب داخل مخزن، آن را با آب آشامیدنی مخلوط کنید.

تنظیم دما



-سیم برق را به یک پریز دارای اتصال زمین وصل کنید ، اتو را در حالت عمودی قرار دهید و تنظیم گر دما را بر روی دمای مناسب با جنس لباسی که میخواهید اتو کنید، تنظیم کنید. برای افزایش دما، تنظیم گر را در جهت حرکت عقربه های ساعت بچرخانید، اگر به بخار نیاز دارید، تنظیم گر دما را روی محدوده علامت بخار تنظیم کنید.


هنگام تنظیم درجه حرارت، از جدول زیر استفاده کنید.

نوع پارچه	درجه حرارت	بخار
ترکیبات مصنوعی	•	عدم استفاده از بخار
ابریشم	•	عدم استفاده از بخار
پشمی	••	پیشنهاد استفاده از بخار
نخی	•••	استفاده از بخار
لنین - جیر	Max	استفاده از بخار

- به منظور مشخص شدن نوع پارچه لیبل لباسها را بررسی کنید تا دمای مناسب اتوکشی را انتخاب کنید.




- اگر از نوع یک پارچه مشخص مطمئن نیستید، بر روی یک قسمت ناپیدا از پارچه اتوکشی را امتحان کنید تا تنظیم درجه حرارت مناسب را پیدا کنید.

- برای جلوگیری از ایجاد لکه های روشن روی پارچه های ابریشمی و ترکیبات مصنوعی هنگام اتوکشی، آنها را برگردانید و اتوکشی کنید تا جایی که امکان دارد از عملکرد اسپری استفاده نکنید، در غیر اینصورت ممکن است لکه ایجاد شود.




تنظیم‌گر بخار را بر روی بر روی محدوده دلخواه تنظیم کنید.


اگر می‌خواهید اتوکشی را با بخار انجام دهید، تنظیم‌گر دما را روی درجه بخار قرمز رنگ تنظیم کنید. زمانی که چراغ ترموستات خاموش شد، کفی برای تولید بخار آماده است.



برای اتوکشی خشک، تنظیم‌گر بخار را در جهت خلاف عقربه‌های ساعت به حالت "0" قرار دهید. دقت کنید که مخزن آب خالی نباشد، بنابراین هر زمان که تمایل داشتید می‌توانید از دکمه اسپری‌کننده استفاده نمایید.




برخی از چروک‌های عمیق را با فشار دادن دکمه بخار لحظه‌ای برای ۳ یا ۴ مرتبه به فاصله ۵ ثانیه برای تولید بخار لحظه‌ای قوی، می‌توان صاف کرد.



بخار لحظه‌ای ممکن است تا زمانی که اتو به دمای مناسب برسد تولید نشود. برای تولید بخار لحظه‌ای، تنظیم‌گر دما باید روی ●●● یا بالاتر قرار گیرد.

لازم به ذکر است در صورتی که از بخار لحظه ای برای مدت زمان زیادی استفاده شود ، امکان پخش آب و بخار به صورت همزمان از کفی وجود دارد.

اسپری آب



در صورت وجود آب به میزان لازم داخل مخزن ، هنگام اتوکشی خشک و بخار دکمه اسپری کننده را برای صاف کردن چروکهای عمیق فشار دهید.

بخار عمودی



در صورتی که اتو را در حالت ایستاده نگه داشته اید، دکمه بخار لحظه ای را فشار دهید، بخار به صورت عمودی پخش خواهد شد. بنابراین بخار می تواند برای پارچه های مشخصی بدون برداشتن آنها از روی رخت آویز مورد استفاده قرار گیرد. این روش می تواند برای اتوکشی پرده ها بدون درآوردن آنها استفاده شود.


توجه: هرگز روی لباسهای افراد که بر تن دارند و یا حیوانات خانگی بخار مستقیم نگیرید.

عملکرد ضد رسوب


مخزن آب این دستگاه مجهز به سیستم ضد رسوب می باشد ، بنابراین خروجی بخار مسدود نخواهد شد. این سیستم همیشه فعال بوده و نیازی به تعویض ندارد.

خود تمیزکاری


این دستگاه لایه های آهک انباشته شده در مخزن بخار را از بین میبرد. روش تمیزکاری شرح داده شده زیر را هر ۲ یا ۳ هفته یکبار اجرا کنید. اگر آب لوله کشی محل زندگی شما بسیار سخت است (دارای آهک می باشد) و رسوبات آهک از کفی اتو میریزد، از این روش بیشتر استفاده کنید.




- حتما سیم برق را از پریز جدا کنید.
- مخزن را با آب تا علامت MAX پر کنید.




- سرکه ، شوینده رسوب زدا وغیره را به آب درون مخزن اضافه نکنید.
- درجه تنظیم گر بخار را روی "0" تنظیم کنید.




-سیم برق را به یک پریز دارای اتصال زمین وصل نموده و تنظیم گر دما را روی درجه Maximum قرار دهید.




- زمانی که چراغ هشدار ترموستات خاموش شد ، سیم برق را از پریز جدا کنید.



- اتو را روی سینک نگه دارید ، تنظیم گر بخار را به سمت خود تمیز کاری بکشید (صدای کلیک را خواهید شنید) و درجه را تغییر دهید ، اتو را به چپ و راست تکان دهید. در نتیجه آب داخل مخزن به قسمت بخار میریزد و رسوبات آهک (اگر وجود داشته باشد) از سوراخ های کفی خارج می شوند.




- درجه تنظیم گر بخار را بعد از خالی شدن مخزن از آب تغییر دهید. در صورت باقی ماندن رسوبات آهک ، این رویه را تکرار کنید.




- بعد از اجرای خود تمیز کاری ، سیم برق را به پریز وصل کنید و اجازه دهید اتو داغ شود. بعد از رسیدن اتو به دمای تنظیم شده سیم برق را از پریز جدا کنید و اتو را به آرامی روی یک تکه پارچه قدیمی حرکت دهید . تا زمان خارج شدن کامل آب و رسوبات آهکی باقی مانده حرکت دادن را ادامه دهید. قبل از جمع کردن اتو، اجازه دهید تا سرد شود.

بعد از اتوکشی



بعد از اتمام اتوکشی ، سیم برق را از پریز جدا نموده و مخزن را از آب تخلیه کنید.



برای تخلیه کردن مخزن ، درپوش آن را باز کرده و اتو را به جلو و پایین حرکت دهید. اجازه دهید اتو سرد شود. با یک پارچه مرطوب زمانی که هنوز دستگاه گرم است آن را پاک کنید.

مشکلات و راه حل ها

مشکل	دلایل احتمالی	راه حل
- سیم برق به پریز متصل است اما کفی داغ نمی شود.	- اتصال به خوبی برقرار نشده. - تنظیمگر دما بر روی حالت خاموش تنظیم شده.	- دوشاخه و پریز برق را بررسی کنید. - تنظیمگر دما را روی علامت بخار تنظیم کنید.
- اتو ، بخار تولید نمی کند.	- آب کافی در مخزن وجود ندارد. - تنظیمگر بخار روی 0 تنظیم شده.	- آب را داخل مخزن تا علامت MAX پر کنید. - تنظیمگر بخار را روی علامت بخار تنظیم کنید. - ممکن است کفی به اندازه کافی داغ نشده باشد. ممکن است سیستم ضدچکه در حال اجرا باشد. تنظیمگر دما را روی علامت بخار بچرخانید. اتو را در حالت عمودی قرار دهید و تا زمان داغ شدن کفی صبر کنید.

مشکل	دلایل احتمالی	راه حل
- عملکرد بخار عمودی و لحظه ای کار نمی کند.	- ممکن است این عملکرد به صورت مداوم در زمان کوتاهی مورد استفاده قرار گرفته باشد.	- اتوکشی افقی را ادامه دهید و قبل از استفاده دوباره این عملکرد صبر کنید. - ممکن است کفی به اندازه کافی داغ نشده باشد. تنظیم گر دما را به سمت علامت بخار بچرخانید. اتو را در حالت عمودی قرار دهید و تا داغ شدن کفی صبر کنید.
- آب روی پارچه می چکد.	- درپوش مخزن آب به خوبی بسته نشده.	- درپوش را به درستی ببندید.
- رسوبات و ذرات هنگام اتوکشی روی پارچه می ریزد.	- آب داخل مخزن بسیار آهکی باشد.	- عملکرد خودتمیزکاری را یکبار یا بیشتر انجام دهید. برای استفاده بعدی مخزن را با آب بدون سختی پر کنید.
- هنگامی که اتو سرد شده یا جمع شده آب از آن می چکد.	- آب داخل مخزن وجود دارد و اتو به حالت افقی قرار داده شده است.	- مخزن آب را تخلیه کنید.

بازیافت

این محصول را نباید همانند زباله های عادی خانگی دور انداخت؛ چرا که حاوی موادیست که باعث آسیب به طبیعت می شود. پس لطفاً در زمان پایان عمر دستگاه، آن را به مراکز رسمی بازیافت پسماند تحویل دهید.



Sanjeh

شرکت بازرگانی سنجه کیش

خدمات پس از فروش از طریق پست در سراسر کشور

با شماره تلفن: ۰۲۱-۲۳۲۸-۲۳۲۸ تماس حاصل فرمایید.



واحد امور مشتریان توضیحات نحوه‌ی خدمات پستی را ارائه خواهند داد.



کالای خود را به مامور پست تحویل دهید.



کالای شما در خدمات پس از فروش مرکزی توسط تکنسین مجرب تعمیر خواهد شد.



کالای تعمیر شده، بازبینی و بسته‌بندی خواهد شد.



کالا در اسرع وقت توسط مامور پست درب منزل شما، تحویل داده خواهد شد.



GSI 230

Dear customer!
Thanks for your worthwhile choice and confidence to Migel brand. We really hope that you enjoy operating this product

TECHNICAL DATA

Model	Power	Frequency	Voltage
GSI230	1950-2300 W	220-240 V	50/60 Hz

Important Rules


1. Read this user's manual carefully before using this laundry iron, and store this manual for future reference.
2. Before plugging the iron's power cord in a wall outlet, be sure the municipal voltage matches the type label on the back of your iron.
3. Always plug out the iron's power cord before filling water in its reservoir and emptying its reservoir. Hold the plug, not the cord itself, while plugging the power cord out.
4. Always empty the iron's water reservoir after finishing with ironing. Be sure to plug out its power cord before emptying its reservoir.
5. Keep the power cord away from hot objects and the iron's base plate.
6. Always plug the power cord in a grounded wall outlet. If you need to use an extension cord, it must contain a ground line and its cross section must be minimum 1 mm².
7. To avoid electric shock, do not immerse the iron in a liquid.
8. To avoid risks, always use the iron on a flat and fixed surface.
9. Lay the iron on vertical position after finishing with ironing and wait until it cools, and do the same before taking a break from ironing. Be sure to lay the iron on a fixed and flat surface.
10. Electric appliances are not a toy. Use and keep the iron away from children. Do not leave it unattended near children while it is hot.
11. Never attempt to iron, wet or moist any of the clothes while wearing them on you.
12. If the power cord is damaged, ensure your local service shop to replace it in order to avoid hazard risks.
13. Never use the iron after it falls on the ground is damaged or leaks water. Call your local service shop immediately.
14. If the iron is broken down in any way, do not use it and take it to your local service shop
15. This iron must not be used by physically (sight or hearing) disabled persons, mentally disabled persons, children or inexperienced persons

unless they are supervised by a responsible person.

16. If this iron is used by a child, supervise him/her at all times and be sure him/her not to toy with it.

17. This iron meets the applicable international safety standards.

Technical Properties



- | | |
|-----------------------------|---------------------------------|
| 1. Power cable | 6. Steam setting dial |
| 2. Temperature setting dial | 7. Water spray button |
| 3. Base plate | 8. Shock steam button |
| 4. Water spray | 9. Base plate temperature light |
| 5. Water Inlet Cover | |

Important notes on using the iron

1. Do not fill the iron's water reservoir excessively, otherwise it might overflow. To avoid overflowing, hold the iron in vertical position and fill water in its reservoir up to the MAX mark.

2. The base plate of the iron should be heated to a certain degree before generating steam. When its temperature dial is set to steam and its steam button is pressed, the anti-drip function will prevent it from dripping water until its base plate is heated enough.

3. This iron was designed for use of tap water. Before using this iron for the first time, fill water in its reservoir, let it vaporize the water, and repeat this process a second time. While vaporizing is in process, press the steam button at frequent intervals. Thus vaporizing performance will improve, and dust particles will be cleaned off the water troughs.



4. If your local tap water is too calcareous, you are recommended to mix it with potable water before filling the iron's water reservoir.
5. When you use this iron for the first time, a slight smell might occur. It will normalize after using it a few times.
6. If the reservoir runs out of water during ironing, plug out the power cord from the wall outlet and add water in the reservoir without waiting the iron to cool.
7. If the spray function does not work, close the spray outlet with your finger and press the spray button a few times to remove any clog.
8. Clothes requiring low temperature should be ironed first, those requiring high temperature should be ironed later. If you reduce the temperature setting from a high degree to a low degree, you have to wait 3-4 minutes until the iron cools down to the low degree.
9. The anti-drip function of this iron makes its base plate emit a "click" sound when its temperature changes; it is normal.
10. Before using this iron for the first time, remove the protective cover from its base plate.

How to use the iron

Always plug out the power cord from the wall outlet before filling water in the reservoir.


How to fill water in the reservoir

- Plug out the power cord from the wall outlet. Turn the steam dial clockwise to "off" position.
- Open the reservoir's lid, hold the iron in horizontal position, slightly lower its front end and fill water in its reservoir. Be sure the water level not to exceed the MAX line marked on the transparent water reservoir of the iron when the iron is held in vertical position.
- Close the reservoir's lid.
- You are recommended to fill water in the reservoir even if you would not use steam for ironing, thus you can use the spray function when you want.
- Do not add any perfume, vinegar and starch, decalcification agents, ironing supplements or other chemical materials in the water reservoir.
- If your local tap water is too calcareous, you are recommended to mix it with potable water before filling the iron's water reservoir.



How to set the temperature

- Plug the power cord in a grounded wall outlet, set the temperature dial to a temperature proper for the clothes you will iron, and lay the iron in vertical position. To increase the temperature level, turn the dial clockwise. If you would steam, set the temperature dial to the red steam range mark. are recommended to mix it with potable water before filling the iron's water reservoir.




You are recommended to follow the table given below while setting a temperature level. The indicator will change to the color described below for each temperature range.

Type of clothe	Temperature range	Steam
Synthetic	•	Do not use steam
Silk	•	Do not use steam
Wool	••	Steam is recommended
Cotton	•••	Use steam
Linen-denim	Max	Use steam


- Check the labels of clothes to verify the proper ironing temperature setting.
- If you are not sure about the type of a particular clothe, make a test ironing on an invisible part of the clothes to find out the proper temperature setting.
- To avoid silk or other synthetic clothes to develop bright stains during ironing, iron their reverse surfaces. Does not use the spray function as far as possible, otherwise stains might develop.

Steam ironing

Adjust the steam dial to set it to the range you want.




If you would steam ironing, set the temperature dial to the red steam range. When the thermostat's light turns off and the base the base plate is ready to generate steam.



Dry ironing

For dry ironing, turn the steam dial clockwise to "off" position.



You are recommended to have water in the reservoir, so that you can use the spray button when you want.



Shock steam

Some stubborn creases can be flattened by pressing the shock steam button 3 or 4 times every 5 seconds to generate a strong steam shock.


Shock steam might not be generated until the iron reaches a proper heat. To generate shock steam, the temperature dial must be set to **••** or higher.



Strong steam shock generated by pressing this button helps to iron stubborn creases. However, if shock steam is applied for a long time, the base plate might emit water together with steam.


Water spray

If there is enough water in the reservoir, press the spray button to flatten stubborn creases while doing dry or steam ironing.



Vertical steam

If you press the shock steam button while holding the iron in vertical position, it will emit vertical steam. Thus steam can be applied on certain clothes without removing them from their hangers. This method can be used for ironing the curtains without removing them. Never direct the steam on clothes on people or pets.



Auto-Off

This iron contains an automatic shut-off mechanism in case it is left powered and unattended.

8-Minute Delay


After you plug the power cord in a wall outlet and lay the iron in vertical position, it will reach the temperature level you have set in 2-3 minutes. If the iron is not moved for 8 minutes, the auto-off function will assume you forgot it and turn it off.

2-Minute Delay

If you plug the power cord in a wall outlet, lay the iron in horizontal position and do not move it for 2 minutes, the auto-off function will assume you forgot it and turn it off.


30-Second Delay

If you let the iron heat for the first time in horizontal position and do not move it for 30 seconds, the auto-off function will assume you forgot it and turn it off.



In either of the three cases described above, the soleplate auto-off light will blink to warn the user.

If you move the iron in horizontal position, it will resume operating and heating.




Anti-Calc System

The water tank of this iron contains an anti-calc system, so that steam outlet will not be clogged. this system remains active at all times, and does not need to be replaced.


Self Clean

This unit removes lime layers accumulated in the steam chamber of the iron. Apply the self-clean procedure described below every 2 or 3 weeks. If your local tap water is too hard (i.e. scales of lime falls from the base plate), you are recommended to apply this procedure more frequently.


- Be sure to plug the power cord out of the wall outlet.
- Fill the reservoir with water up to the MAX level mark.




- Do not add vinegar, decalcifying agent, etc. in the water reservoir.
- Turn the steam dial no steam setting of '0'.




- Plug the power cord in a grounded wall outlet and turn the temperature dial to maximum level.




- Plug the power cord out of the wall outlet after the thermostat warning light turns off.




- Pull the iron on a washbasin, pull the iron steam setting dial to the self clean side (you will hear click sound) and displace the dial, shake the iron up and down. Thus the water in the reservoir falls down to the steam chamber, and scales of lime (if any) will fall out of the base plate's holes.



- Replace steam setting dial after the water reservoir empties. If there still are scales of lime, repeat this procedure.




- After finishing the self-clean procedure, plug the power cord in a wall outlet and let the iron heats. Plug the power cord out of the wall outlet after the iron reaches the temperature set and move the iron slowly on an old piece of cloth. Continue to move it until remaining water and scales of lime are cleaned off. Let the iron cool before storing it.




After ironing

After finishing with ironing, plug the power cord out of the wall outlet. Empty the water reservoir.



To empty the water reservoir, open its lid and tilt the iron's front end down. Let the iron cool. Wipe it with a moist cloth while it is still warm.



Maintenance and cleaning

Soft metals and materials (buttons, zips, etc.) will not damage the base plate under normal ironing conditions. Stains which might be left by such materials on the base plate can be cleaned off with a piece of cloth soaked with eau de toilette or detergent.

PROBLEMS AND SOLUTIONS

Problem	Possible Reasons	Solution
- The power cord is plugged in, but the base plate does not heat.	- Connection is bad. - Temperature dial is set to minimum range.	- Check the plug and wall outlet. - Turn the temperature dial to the steam mark.
- The iron does not generate steam.	- No sufficient water in the reservoir. - Steam dial is set to 0.	- Fill water in the reservoir up to the MAX line. - Turn the steam dial to the steam mark. - The base plate might not be hot enough. Anti-drip system might be operating. Turn the temperature dial to the steam mark. Lay the iron in vertical position and wait until its base plate heats.
- Shock steam-vertical steam function does not operate.	- This function might have been used too frequently in a short time.	- Continue to horizontal ironing and wait before using this function again. - The base plate might not be hot enough. Turn the temperature dial to the steam mark. Lay the iron in vertical position and wait until its base plate heats.
- Water drops fall on the clothes.	- Lid of the water reservoir is not fully closed.	- Close the lid properly.
- Sediments and particles fall from the base plate during ironing.	- Water in the reservoir is too calcareous.	- Use the self-clean function once or more. Fill the reservoir with soft water next time.

Problem	Possible Reasons	Solution
- Water drops fall from the iron after it cools or is stored.	- There is water in the reservoir and the iron is laid horizontal.	- Empty the water reservoir.

Environment



- Do not throw away the appliance with the normal household waste at the end of its life, but hand it in at an official collection point for recycling. By doing this, you help to preserve the environment.

MIGEL



English

فارسی

Steam Iron

GSI 230